



Figure 6.9 A typical layout for framing a wall includes openings for doors and windows. Rough openings need not and often do not correspond to the regular stud spacing.